





5-1. MAIN





5-2. FRAME & COVER PARTS




This diagram shows the exploded view of the washing machine door assembly. The components include the door panel with a mesh screen, the door frame, the door hinge mechanism, the door lock, and the door latch. The diagram illustrates how these parts fit together to form the complete door assembly.





5-4. ASS'Y FRAME FRONT




54 _ Exploded views and Parts list





5-5. PANEL-CONTROL & DRAWER





5-6. ASS'Y HOUSING DRAWER

